

1060 Uni Pro Seat  
& Suspension  
PN: 8132



### Note!

Weight needs to be applied to the suspension to activate the pump.

### Installation Instructions to Place a 1060 Uni Pro Seat and Suspension in a Ford 7410, 7700, 7710, 7810, 7910, 8210, 8630, 8700, 8730, 8830, 9030, 9700 or TW Series Tractor

1. Remove the original seat and suspension from the tractor.
2. Bolt the seat and suspension assembly to the tractor deck using the original bolts. **Drilling will be required.**
3. Locate a power source and connect the suspension to power and ground. **(See note below.)**

### Note!

There are two wire connections in the 1060 Uni Pro, one for the Operator Presence Switch (OPS) and one for the compressor. The OPS wires come out of the back of the seat and the compressor wires are tucked in the boot. The OPS wires do not need to be connected for the seat to function. Connection of the OPS is only necessary if required by the machine or desired by the operator.

Cutaway of  
Tractor Deck

