

Installation Guide

Nite-Gard™ JD 8020/8030
(PN: 3244)

1. Mount the left hand bracket to the lower door hinge. Remove the top bolt first and reinstall it, running it through the top hole of the LH mount bracket. Then remove the bottom bolt and reinstall it, running it through the bottom hole of the mount bracket. Removing both bolts at the same time can cause the door to shift and make it more difficult to install. (Left hand assembly shown in the picture)
2. On the right side, install the bracket using the existing bolts that are used to hold the back lower part of the right window. Remove the bolts and install the right hand mount bracket on top of the window plate.
3. Mount the warning light arm to the horizontal mount bracket using the 3/8" x 1" bolts and flange nuts.
4. Locate the flasher circuit on the tractor.
5. Connect one wire to the flasher circuit and ground the other wire. Be sure to trim the wire on the warning light arm and discard any excess wire.
6. Loosen the knob and extend the light extension to desired position.
7. Re-tighten the knob. Do not over tighten.

