

Installation Guide

JD 850 COMPACT SERIES (PN: 6885 - Yellow, 6886 - Black)

BOLT LOCATIONS

1. Remove the original seat. Save the mounting hardware for reuse.
2. Attach the PN: 6028 PED Plate onto the PN: 7937 or the PN: 7927 with four 5/16-18 X 1 cap screws and lock washers into the holes marked in picture 1.
3. Attach seat onto tractor suspension with the original bolts in the desired location for operator comfort.



Picture 1

PN: 6028 - JD 850 Compact
Tractor Adapter Plate



Picture 2