

1. Remove the stationary hooks on the back of the cab if they are there.
2. Mount the Sound-Gard™ bracket using the holes and 1/2" bolt that the hooks mounted with. The hooks can be installed on top of the bracket or left off. (Right hand mounting shown in picture)
3. The plate for the Sound-Gard™ bracket will be under the fender. Use the plate to mark the holes for the mounting bracket.
4. Drill four 13/32" holes for the mounting bracket.
5. Place the fender mount bracket on the top of the fender and line up the holes with the Sound-Gard™ mount. Fasten together using 3/8" x 1 1/2" carriage bolts, lock washers, and nuts.
6. Mount the warning light arm to the fender mount bracket using the 3/8" x 1" bolts and flange nuts.
7. Locate the flasher circuit on the tractor.
8. Connect one wire to the flasher circuit and ground the other wire. Be sure to trim the wire on the warning light arm and discard any excess wire.
9. Loosen the knob and extend the light extension to desired position.
10. Re-tighten the knob. Do not over tighten.

