

Instruction Guide 6505



Installation Instructions to Place a 1004 Uni Pro Seat and Suspension in an AC 7000 Series Tractor

- Remove all of the original suspension and slide rail mechanisms. Remove the angle bracket from the cab deck. (You must get down to the bare angled cab deck.)
- 2. Attach the PED AC 73 by using two of the existing holes in the lower cab panel. **(Fig. A)** Fasten with two 5/16" x 1" bolts and lock washers.
- 3. Drill two new holes into the vertical deck plate to correspond with the bottom holes in the pedestal support frame. (Fig. B) Fasten with two 5/16" x 3/4" bolts and flange nuts.
- 4. Bolt the seat and suspension assembly to the pedestal with four 5/16" x 3/4" bolts and flange nuts.

