

Instruction Guide 6513



Installation Instructions to Place a 1004 Uni Pro Seat and Suspension in Agco Allis or Agco White Tractors

- 1. Remove the original seat and suspension.
- 2. Bolt the seat and suspension assembly to the cab floor with four 5/16" x 1" bolts and flange nuts. **Drilling may be required.**