

## **Installation Guide 6729**



## Installation Instructions to Place a 1060 Uni Pro Seat and Suspension in a CIH 7100 Magnum Series with Air-Oil Suspension

- 1. Remove the original seat and suspension from the tractor.
- 2. Install the PED CIH Magnum using the original bolts.
- 3. Bolt the new seat and suspension assembly to the PED CIH Magnum angles using the included hardware.
- 4. Locate a power source and connect the suspension to power and ground. (See note below.)

## Note!

There are two wire connections in the 1060 Uni Pro, one for the Operator Presence Switch (OPS) and one for the compressor. The OPS wires come out of the back of the seat and the compressor wires are tucked in the boot. The OPS wires do not need to be connected for the seat to function. Connection of the OPS is only necessary if required by the machine or desired by the operator.