

1. Lower the three point hitch.
2. Remove the old seat and suspension from the tractor.
3. Remove the slide rails from the new seat and re-install them to the wider 13" mounting.
4. Place four 2" spacer bushings onto where the original suspension was mounted. (See picture 1 below)
5. Mount the 6120 PED plate on top of the spacer bushings and to the tractor using four 8mm x 1.25 x 70mm bolts and four lock washers. (See assembly diagram on the next page)
6. Use the 86419 wiring harness and butt connect the wires to the tractor as described below.
 - Red - To keyed power on the tractor. (Used only on the KM 136 Air Kit)
 - Black - To tractor ground. (Used only on the KM 136 Air Kit)
 - Green - To blue and black on the tractor's OPS switch wiring harness.
 - White - To light blue on the tractor's OPS switch wiring harness.
 - Yellow - To red and black on the tractor's OPS switch wiring harness.
7. Secure the wiring harness to the KM 6120 plate using the zip tie provided. Use the two small holes at the center rear to route the zip through.
8. If armrests or a seat belt kit were purchased, install at this time.
9. Mount the seat to the 6120 PED plate using four 5/16" x 1 1/2" button head socket cap screws, .385" spacer bushings, and flange nuts. The spacer bushing go in between the seat and the 6120 PED plate. (See assembly diagram on the next page)
10. Tighten all hardware and connect the seat wiring harness to the tractor wiring harness.

Picture 1



Installation Guide

Kubota KM 136 Seat Kit (PN:6883 & 6884)

