

### MONITOR BRACKET FOR JD 6000 & 6010 SERIES

1. Locate the four tapped 10mm holes in the center and right side rear cab posts.  
(They may have plastic inserts that will turn out.)
2. Attach Bracket A to center post with two 10mm bolts then attach Bracket B to rear post also with 10 mm bolts. (Finger tight only.)
3. Attach Brackets C and D to A and B with two 1/4-20 x 1 carriage bolts nuts and washers in B and two 1/4-20 x 3/4 carriage bolts washers and nuts in A.
4. Attach front of Brackets C and D with a 1/2 -13 x 1 carriage bolt washer and nut.
5. Tighten all hardware.

