

John Deere Left Hand Utility Step Kit Installation (PN: 3435)

1. Remove plastic plugs from the top two holes on the left side of the frame.
2. If you have a toolbox mounted in the same location that the step is to be mounted, move it to the lower two holes so it is below the step.
3. Fasten the step to the step bracket using four $\frac{3}{8}$ " x $1\frac{1}{4}$ " bolts and serrated flange nuts.
4. Fasten the step bracket to the offset plate using two $\frac{3}{4}$ " x 2" carriage bolts, lock washers, and nuts.
5. Mount the step bracket and offset bracket to the frame of the tractor using two 20mm x 50mm bolts and lock washers.

