

Installation Guide 6722



Installation Instruction to Place a 1060 Uni Pro Seat and Suspension in Agco Allis or Agco White Tractors

- Remove the original seat and suspension from the tractor.
- Bolt the seat and suspension assembly to the deck of the tractor cab with four 5/16" x 1" bolts and flange nuts. Drilling may be required.
- 3. Locate a power source and connect the suspension to power and ground. (See note below.)

Note!

There are two wire connections in the 1060 Uni Pro, one for the Operator Presence Switch (OPS) and one for the compressor. The OPS wires come out of the back of the seat and the compressor wires are tucked in the boot. The OPS wires do not need to be connected for the seat to function.

Connection of the OPS is only necessary if required by the machine or desired by the operator.