



5/16"-18x3/4" HEX HEAD BOLTS



5/16" LOCK WASHERS

Installation instructions for KM129 seat onto a Kubota B2650

1. Remove old seat. Keep the hinge pin and cotter pin to be used installing new seat.
2. Install KM bracket kit on KM129 seat as shown below using 5/16"-18x3/4" and 5/16" lock washers. NOTE: Use hardware provided to ensure use of proper threads.
3. Tighten bolts.
4. Install new seat using seat hinge pin and cotter pin from old seat.

NOTE: Bottom of seat shown for clarity.

BACK OF SEAT

