

Installation instructions for KM125/129 seat onto a Kubota BX2230



5/16"-18x3/4" HEX HEAD BOLTS



5/16" LOCK WASHERS



5/16"-18 FLANGE NUTS

1. Remove old seat. NOTE: Sliding the seat forward or back will allow access to the bolts.
2. Mount PED (PN: 10986) to new seat bottom using 5/16"-18x3/4" hex head bolts and 5/16" lock washers. The welded studs should be placed toward the front of the seat.
3. Mount seat to tractor using 5/16" flange nuts. NOTE: You may need to slide seat forward or back to allow access to studs.

NOTE: Bottom of seat shown for clarity.

