



1. Unplug the OPS switch wire from the side of the suspension.
2. Remove the cotter key and pull the pin out to remove the old seat.
3. Remove the old suspension by taking out the 8mm bolts holding it in place.
4. Install the 10987 PED plate where the old suspension mounted. Use four 8mm-1.25 x 60mm button head socket cap screws and 1 3/4" spacer bushings. The spacer bushing go below the 10987 PED plate.
5. If armrests or a seat belt kit were purchased, install at this time.
6. Mount the new seat to the 10987 PED plate using four 5/16"-18 x 1" button head socket cap screws, .225" spacer bushings, and flange nuts. The spacer bushings go in between the seat and the 10987 PED plate.
7. Connect tractor wiring to the 86419 harness provided as described below.
  - Red - Add additional wire and route to keyed tractor power. (Air Seat Kits ONLY)
  - Black - Add additional wire and route to tractor ground source. (Air Seat Kits ONLY)

OPS Switch - Cut the plug off the original seat, leaving as much wire as possible and Splice to the 86419 harness.

Normally Open OPS Switch

- Yellow - To tractor OPS switch plug.
- White - To tractor OPS switch plug.

Normally Closed OPS Switch

- Green - To tractor OPS switch plug.
- White - To tractor OPS switch plug.

8. Connect the 86419 harness to the seat and the OPS switch plug to the tractor.