



10989 ADAPTER PLATE

1. Unplug wiring connector located at the rear of the seat on the floor of the cab. Remove the 4 nuts at the corners of the suspension. Save the nuts to use on the new suspension.
2. Remove the old seat and suspension. You may want to remove the rear window for this step.
3. Prepare the new seat for installation.
 - A. If installing swivel follow the instructions provided with the swivel.
 - B. Attach the 10989 Adapter Plate with the "notch" to the front with four 8mm bolts and lock washers.
 - C. Cut the wiring plug from the old seat leaving 2 inches of wire for the butt connectors to attach the plug to the suspension.
Green and Yellow for OPS.
Red and Black for compressor.
4. Attach the new seat to cab floor using the nuts removed in step one and plug in connector.