

Installation Guide

Installation Instructions for KM 1310 Uni Pro Seat & Suspension in Case IH 9100 & Steiger Series Tractors (PN: 6907)

KM 1310
Uni Pro Seat &
Suspension
PN: 8553



1. Remove the original seat and suspension from the tractor by removing four ½ inch nuts from the base bracket attaching the seat to the floor of the cab.
2. Bolt the KM 1310 Uni Pro seat and suspension assembly to the pedestal PN 6127 using four 8mm x 20mm bolts, flat washers and flange nuts.
3. Attach seat and pedestal to the four stud bolts and spacers where the original seat was removed. Use the original hardware to fasten down the seat. Locate power cable coming from lower part of suspension and connect to 10 amp 12volt connection of the tractor.

NOTE: Installation kit has wiring harness or adapter to allow plug and play on most applications.

NOTE: The KM 1310 comes equipped with an Operator Presence Switch. Some tractor models do not have OPS and the harness can be tied up and tucked out of the way.

Optional
Swivel Kit
Available
PN: 5007

PN: 6127

