

Installation Guide

Case F Series Wheel Loader KM 1200 Kit (PN: 6956)

1. Remove original seat and suspension.
2. Place the PED 6144 into the cab in the location that the original seat was. Use four 10 mm x 40 mm flat head socket cap screws to fasten down.
3. Place the KM 1200 seat onto the four studs and fasten in place using two 5/16" flange nuts on the front two studs and two 3/8" flange nuts on the rear studs.
4. Connect the seat power connector to the wheel loader's seat connector. **NOTE:** If your original seat was mechanical, you will have to run a 24 volt power and ground to the seat. Keyed power is recommended.

