

Installation Guide

Case F Series Wheel Loader KM 1201 Kit (PN: 6957)

1. Remove original seat and suspension.
2. Mount the KM 1201 seat to the PED 6144 using four 8 mm x 20 mm flat head socket cap screws.
3. Place the seat and PED assembly into the cab in the location that the original seat was. Use four 10 mm x 40 mm flat head socket cap screws to fasten down.
4. Connect the seat power connector to the wheel loader's seat connector. **NOTE:** If your original seat was mechanical, you will have to run a 24 volt power and ground to the seat. Keyed power is recommended.

