

Installation Guide

Case F Series Wheel Loader KM 722 Kit (PN: 6958)

1. Remove original seat and suspension.
2. Mount the KM 722 Seat to the 6144 PED using four 5/16" x 3/4" flat head socket cap screws and flange nuts. NOTE: You will have to raise the suspension and remove the lower part of the rubber boot in order to get the nuts on to the screws.
3. Install the armrests onto the seat using the hardware and instructions provided with the armrest kits.
4. Place the seat and PED assembly into the cab in the location that the original seat was. Use four 10 mm x 40 mm flat head socket cap screws to fasten down.

