

1. Remove the original seat and suspension from the cab.
2. Place the PED 6145 into the cab and fasten down using four 8 mm x 25 mm flat head socket cap screws.
3. Remove the armrests from the new seat.
4. Place the seat into the cab onto the studs that are on PED 6145 and fasten in place using four 5/16" center lock nuts. **NOTE:** If you are installing a 1098 (PN: 8035) or a 1099 (PN: 8034) seat you will have to adjust the slide rails and move the seat forwards and backwards to get the nuts on.
5. If you are installing an air suspension seat, cut off the electrical connector from the OEM seat and splice it onto the new seat.

