




Original
Air Seat
without Swivel



SAP CIH
Magnum
PN: 6099



Swivel 50
PN: 5005
Optional



Slide Rails
PN: 6047



Deluxe Mechanical
Suspension
PN: 6083

Note!

Weight needs to be applied to the suspension to turn the mechanical knobs.

Installation Instructions to Place a Mechanical Suspension in a CIH 71, 72 & 89 Magnum 4WD Series or 91, 92, 93 Series Steiger, Cougar or Panther with Original Air Seat without Swivel

1. Remove the original seat and suspension.
2. Place the suspension on the existing pedestal and mark holes for drilling. Drill 3/8" holes, then bolt down the suspension with four 5/16" x 3/4" bolts and flange nuts.
3. Fasten the slide rails to the suspension with four 5/16" x 1" bolts, 7/16" spacer nuts and flange nuts.
4. If installing a swivel, fasten the swivel to the slide rails using four 5/16" x 5/8" bolts and flange nuts.
5. Bolt the SAP CIH Magnum to the seat using the original bolts. Fasten the SAP and seat assembly to the swivel or slide rails using four 5/16" x 3/4" bolts and flange nuts.