

Installation Guide 6720



Installation Instructions to Place a 1060 Uni Pro Seat and Suspension in an AC 8000 Series Tractor

- 1. Remove the original seat and suspension assembly.
- Bolt the seat and suspension to the tractor deck with four 5/16" x 3/4" bolts and flange nuts.
 Drilling will be required.
- 3. Locate a power source and connect the suspension to power and ground. (See note below.)

Note!

There are two wire connections in the 1060 Uni Pro, one for the Operator Presence Switch (OPS) and one for the compressor. The OPS wires come out of the back of the seat and the compressor wires are tucked in the boot. The OPS wires do not need to be connected for the seat to function.

Connection of the OPS is only necessary if required by the machine or desired by the operator.

Cut away section of tractor deck.