

1. Attach the step bracket to the toolbox bracket with four 3/8" x 3/4" carriage bolts and flange nuts.
2. Attach the toolbox bracket to the tractor using the bolts provided.
3. Bolt the step bracket to the tractor using the bolts provided.
4. Slide the toolbox into position on the toolbox bracket.

