



Fits:
IH 86/88 Grammer 7/8" armrest shaft. Converts shaft to 1 1/4" to accommodate the 86 armrest.

Tools Needed
 1 - 3/16" Allen Wrench




1. Remove the original armrest from the **seat side bracket** of the seat assembly.
2. Place the **shaft adapter** onto the **original armrest shaft** making sure the smaller threaded hole of the **shaft adapter** is closer to the **seat side bracket** than the large drilled hole is.
3. Line up the large drilled hole of the **shaft adapter** to the threaded hole of the **original armrest shaft**.
4. Insert the **3/8" x 1" socket set screw** into the larger drilled hole of the **shaft adapter**. Screw it in but do not tighten it completely.
5. With the **allen wrench** still in the head of the **set screw**, rotate the **shaft adapter** clockwise for the left hand armrest, or counter-clockwise for the right hand armrest, as far as it will go. While holding the **shaft adapter** in place, tighten the **socket set screw** completely.
6. Place the **86 armrest** onto the **shaft adapter**.
7. Place the **3/8" x 3/8" socket set screw** through the slot in the back of the **86 armrest** and into the threaded hole of the **shaft adapter** and tighten completely.



Fits:
IH 86/88 Grammer 7/8" armrest shaft. Converts shaft to 1 1/4" to accommodate the 86 armrest.

Tools Needed
 1 - 3/16" Allen Wrench



1. Remove the original armrest from the **seat side bracket** of the seat assembly.
2. Place the **shaft adapter** onto the **original armrest shaft** making sure the smaller threaded hole of the **shaft adapter** is closer to the **seat side bracket** than the large drilled hole is.
3. Line up the large drilled hole of the **shaft adapter** to the threaded hole of the **original armrest shaft**.
4. Insert the **3/8" x 1" socket set screw** into the larger drilled hole of the **shaft adapter**. Screw it in but do not tighten it completely.
5. With the **allen wrench** still in the head of the **set screw**, rotate the **shaft adapter** clockwise for the left hand armrest, or counter-clockwise for the right hand armrest, as far as it will go. While holding the **shaft adapter** in place, tighten the **socket set screw** completely.
6. Place the **86 armrest** onto the **shaft adapter**.
7. Place the **3/8" x 3/8" socket set screw** through the slot in the back of the **86 armrest** and into the threaded hole of the **shaft adapter** and tighten completely.