

Installation Guide

John Deere Left Hand Utility Step

(PN: 3435)

1. Remove plastic plugs from top two holes on the left side of the frame.
2. Fasten the **step bracket** to the **offset plate** using the 3/4" x 2" carriage bolts, lock washers, and nuts.
3. If you have a toolbox mounted in the same location that the step is to be mounted, move it to the lower two holes so it is below the step.
4. Mount the **step bracket** and **offset bracket** to the frame of the tractor using the 20mm x 50mm bolts.

