

## Installation Guide

### Left Hand Oliver Step Installation Guide PN: 3308

1. Paint the parts a color of your choosing before installing.
2. Attached the upper step weldment to the tractor frame using the 3/4" x 1" bolts provided.
3. Attach the lower step weldment and handrail using the 3/8" x 3/4", 3/8" x 1" carriage bolts, and 3/8" flange nuts provided. The 1" long bolts go on the side the handrail mounts to.
4. Position the extend-a-step to the back of the upper step section. Using the extend-a-step as template, mark the holes to be drilled. Center punch the holes that you marked and drill with a 3/8" drill bit.
5. Position the extend-a-step and bolt it on with two 3/8" x 1" bolts, lock washers, and nuts that were provided.

