



# Compact Air Suspension


## Top View




## Bottom View



## Front View



## Side View





**Pump Switch**

Push switch to activate pump. Pull to release air.

*Note: Weight must be applied to the suspension to activate the pump.*