

Installation Guide 6593

Installation Instructions to Replace an Air/Oil or Hydraulic Suspension and Seat with a 10004 Uni Pro Seat and Suspension in an IH 86/88 Series Tractor



- 1. Remove the original seat and suspension mechanisms.
- 2. Cap the hydraulic lines with the nuts and plugs provided. Hydraulic lines to be capped below the cab. Cut and plug the breather line by turning a 5/16" bolt into the tube.
- Fasten the 6136 PED to the support bracket with the original bolts and nuts. Use holes so PED is offset to the left.
- 4. Bolt the seat and suspension assembly to the pedestal with four 5/16" x 1 1/4" bolts, spacers and flange nuts.

Phone: 1.800.328.1752 / Website: www.tractorseats.com

