


Installation Guide

Side Mounted Weight Attachment and Handle Modification

1. Fasten the **side weight bracket** to the **weight box** with four 1" x 3 1/2" bolts using the existing holes.
2. With the **side weight brackets** bolted to the **weight box**, hang one weight on each side of the **weight box**. Mark the location of the hole in the weight on both sides of the **weight box**.

3. Remove the weights and drill a 17/32" hole through each side of the **weight box** to match the bolt hole in the weight.
4. Place the 1 1/2" x 2" x 4" spacer between the **weight box** and the first weight. Hang the weights and fasten with a bolt or redi-rod.
5. To convert the **weight box handle** for use with the **auxiliary handle**, cut off the top portion of the existing **weight box handle** 1/2" above the **latch hole**.
6. To use the **auxiliary handle** to dump the **weight box** when the weights are attached, place the **auxiliary handle** over the bottom of the existing **weight box handle**. Secure it with the **locking pin** in the **bottom pin hole**.



7. When not using the **auxiliary handle**, place the **auxiliary handle** over the existing **weight box handle** in an upright position. Secure it with the **locking pin** in the top pin hole of the **auxiliary handle** and the **latch hole** on the existing **weight box handle**.