


### JD Combine Mud Scraper Fits JD 9000 Walker Series Combines



1. Slip the hook of the mounting bracket over the cross tube of the combine frame and fasten to the existing hole with a 3/8" x 1" bolt and flange nut on each side.
2. Drill the second hole on each side of the mounting brackets and attach with 3/8" x 1" bolts and flange nuts.
3. Bolt the two sections of the Main Bar together with four 3/4-10 x 2 bolts, lock washers and nuts.
4. Mount the main bar to the mounting brackets and fasten with two 4" U-bolts and flange nuts.
5. Place the extension bars on top of the main bar and secure with four 4" U-bolts and flange nuts. Adjust to match wheel spacings.
6. Attach the stingers to the extension bars and fasten with the stinger backup plate, eight 1/2" x 6" bolt and flange nuts.